



Controls Reference Sheet



Inputs & Macros

Input	Switch
DPad	DPad
A	A
B	B
C	ZR
X	X
Y	Y
Z	ZL
L	L
R	R
Start	+
Select	-
Home	Home

Input	Switch
Home + Y	Pairing mode
Select + C + Z	Screenshot
L+R+Start 5 seconds	DPad swaps to Left Stick
Down + Start 5 seconds	Swap A/B & X/Y
Left + Start [*] 5 seconds	Classics Layout
Up + Start [*] 5 seconds	Swap L/R & Z/C
Right + Start [*] 5 seconds	Right Analog Mode

For other console controls, please refer to the included manual.

* Requires controller to be updated with latest firmware.

©SEGA